



Title: Creating a Forensic Image using FTK Imager.**A. Creating Forensic Image.**


Step 1: Open AccessData FTK Imager.




Step 2: Go to File -> Create Image Disk and Select Contents of a Folder.




Step 3: Browse & Select the any folder and Click on Finish.



Step 4: Click on Add.



Step 5: Fill all the information and Click on Next.




The 'Evidence Item Information' dialog box contains the following fields and values:

Field	Value
Case Number:	101
Evidence Number:	01
Unique Description:	D Drive
Examiner:	CS_5113-18
Notes:	Evidence found on site

At the bottom, there are four buttons: '< Back', 'Next >', 'Cancel', and 'Help'. The 'Next >' button is highlighted with a blue border.

Step 6: Browse the Destination Folder & Give Image Filename and Click on Finish.




The 'Select Image Destination' dialog box contains the following fields and values:


Field	Value
Image Destination Folder	C:\Users\ameyp\OneDrive\Documents
Image Filename (Excluding Extension)	Evidence
Image Fragment Size (MB)	1500
Compression (0=None, 1=Fastest, ..., 9=Smallest)	6
Use AD Encryption	<input type="checkbox"/>
Filter by File Owner	<input type="checkbox"/>

At the bottom, there are four buttons: '< Back', 'Finish', 'Cancel', and 'Help'. The 'Finish' button is highlighted with a blue border.

Step 7: Click on Start.






Step 8: Click on Close.



B. Check Integrity of Data.


Step 9: Click on Image Summary.






C. Analyze Forensic Image

Step 10: Go to File -> Create Image Disk and Select Image File.



Step 11: Browse & Select the Image File we have created and Click on Finish.



Step 12: Analyzed Image File.

